

ALK101 - xxx

Installation Manual

A -- Main PCBA



A1 X 1 PCS

B -- Loudspeaker



B1 X 1 PCS

C -- Components



C1 X 1 PCS
(antenna)



C2 X 1 PCS
(screw button)



C3 X 1 PCS
(power supply cable)

D -- Screws



D1 X 13 PCS
(M3 X 8MM)



D2 X 16 PCS
(M2 X 10MM)



D3 X 16 PCS
(M2)




D4 X 4 PCS
(M3)



D5 X 4 PCS (M3 X 9MM)

E -- Shell plates

Model	Colour
ALK101-100	transparent
ALK101-101	blue
ALK101-102	red
ALK101-103	green
ALK101-104	orange
ALK101-105	pink
ALK101-106	purple
ALK101-107	light blue
ALK101-108	yellow
ALK101-109	wooden shell



E1




E2



E3



E4



E5




E6

6 PCS


1

Fix four hexagonal copper posts and antenna on the main PCBA




2

Install the main PCBA and speaker in shell plates with screws




3

Connect the speaker to the main PCBA




4

Fix the rest shell plates with the screws



5

Connect the power supply cable and button cap



Installation video



Part 1



Part 2



Part 3